




THE DATASHEET OF SK-16FX-EUROSCOPE







FUJITSU

SK-16FX-EUROSCOPI



CDV1.2

All Rights Reserved



Overview



■ Introduction

- [About the SK-16FX-EUROSCOPE](#)
- [SK-16FX-EUROSCOPE content](#)
- [Test it](#)
- [The hardware](#)
- [The software](#)

■ Try yourself

- [Software examples](#)
- [Program download](#)
- [New project](#)
- [EUROSCOPE](#)


■ Optional tools

■ Contacts



■ Additional documents


- [Schematic 'SK-16FX'](#)
- [Data sheet MB91C03](#)
- [Hardware manual](#)
- [AppNote '16FX I/O'](#)
- [AppNote '16FX CPU'](#)
- [Customer Information](#)
- [EUROSCOPE Reference](#)
- [AppNote 'EUROSCOPE'](#)
- [Customer Information 'EUROSCOPE'](#)



About the SK-16FX-EUROSCOPE




- The **SK-16FX-EUROSCOPE** includes a low-cost evaluation board based on the Fujitsu 16FX microcontroller **MB96340**.
- The **MB96340 Series** includes the following features:
 - Up to 576 KByte Flash Memory
 - Up to 24 KByte RAM
 - Up to 2 CAN controller 2.0B
 - Up to 7 LIN-USART interfaces
 - Two I²C interfaces
 - Timers (ICUs, OCUs, PPGs, others)
 - ADC
 - External interrupts
 - Others



About the SK-16FX-EUROSCOPE




- **Features of the SK-16FX-100PMC (EUROSCOPE) board**
 - Microcontroller MB96F348HSB
 - 1x UART-Transceiver (SUB-D9 connector)
 - 1x USB to serial converter (Type-B connector)
 - 1x High-speed CAN-Transceiver (SUB-D9 connector)
 - 2x LED-Display (7-Segment)
 - 2x 'User' -button
 - 1x 'Reset' -button, 'Reset' -LED
 - All 100 pins routed to pin-header
 - On-board 5V and 3V voltage regulators, 'Power' -LED
 - USB power-supply (external power supply possible)




SK-16FX-EUROSCOPE contents

■ The SK-16FX-EUROSCOPE contains

- SK-16FX-100PMC evaluation board with MB96F348HS
- USB cable, RS232 cable
- Mini CD
 - Documentation, USB driver, Softune Workbench, E
 - „EUROScope lite 16FX“







Test it



- The microcontroller on the SK-16FX-100PMC is already preprogrammed with a simple application.

- Connect the USB cable to your PC and the SK-16FX-100PMC.
- [Install the USB driver from the CD](#)
- Press the ,Reset'- Button
- The SK-16FX-100PMC will automatically start counting
- The count direction can be changed by pressing the key






Test it



Congratulations!

- You finished successfully the first test
- Now you will get more details about the SK-16FX-
- You will learn more about
 - The on-board features
 - How to program the Flash
 - How to start your own application
 - On-chip debugging with EUROscope



The Hardware



■ The jumpers JP4: UART RX select

R-0: UART0=UART'A' / U-1: UART1=UART'B' (USB)

R-1: UART1=UART'A' / U-0: UART0=UART'B' (USB)

JP5: UART T

R-0: UART0=UART

R-1: UART1=UART

S1: Mode selection

PROG: Select the program-mode

RUN: Select the run-mode

JP3: DTR-Reset

Set the jumper to 1-2 to connect the DTR-Signal of the UART connector to the microcontroller reset-pin.

Set the jumper to 2-3 to connect the DTR-Signal of the USB connector to the microcontroller reset-pin.

Some terminal-programs, e.g. Fujitsu's Skwizard, allow to reset the evaluation board by using the DTR-Signal.

JP6: MD0 selection

Close this jumper to control the MD0 level by the RTS signal of the USB interface


JP9: MCU VCC


This jumper can be used to measure the current consumption of the MCU

JP10: 5V / 3.3V

1-2: 5V supply is used

2-3: 3.3V supply is used





The Hardware



■ JP4, JP5 : UART selection

- UART0 and UART1 of the microcontroller can be used typical RS232 SUB-D9 connector and a serial/USB connector
- The jumpers JP4 and JP5 routes the channel to the connector
- UART0 = USB-connector (X4), UART1 = Sub-D9 (X4) (default)
- Setting of Jumper JP4 and JP5: U-0 / R-1

RS232 USB




- UART0 = Sub-D9 (X4), UART1 = USB-connector (X5)

- Setting of Jumper JP4 and JP5: U-1 / R-0

RS232 USB






The Hardware



■ The microcontroller pins

Pin	Pin-name	On SK-16FX- EUROSCOPE used by
1	P02_6/A22/IN2/TTG2/TTG10	
2	P02_7/A23/IN3/TTG3/TTG11	
3	P03_0/ALE/IN4/TTG4/TTG12	
4	P03_1/RDX/IN5/TTG5/TTG13	
5	P03_2/WRLX/WRX/INT10R	
6	P03_3/WRHX	
7	P03_4/HRQ/OUT4	
8	P03_5/HAKX/OUT5	
9	P03_6/RDY/OUT6	
10	P03_7/CLK/OUT7	
11	P04_0	
12	P04_1	
13	Vcc	+ Vcc
14	Vss	GND
15	C	'C' capacitors
16	P04_2/IN6/RX1/TTG6/TTG14	
17	P04_3/IN7/TX1/TTG7/TTG15	

Pin	Pin-name
18	P04_4/SDA0/FRCK0
19	P04_5/SCL0/FRCK1
20	P04_6/SDA1
21	P04_7/SCL1
22	P05_0/AN8/ALARM0/SIN2
23	P05_1/AN9/ALARM1/SOT2
24	P05_2/AN10/SCK2
25	P05_3/AN11/TIN3
26	P05_4/AN12/TOT3/TIN2R
27	P05_5/AN13/INT0R/NMIR
28	P05_6/AN14/INT4R
29	P05_7/AN15/INT5R
30	AVcc
31	AVRH
32	AVRL
33	AVss
34	P06_0/AN0/PPG0




The Hardware



■ The microcontroller pins (cont'd)

Pin	Pin-name	On SK-16FX- EUROSCOPE used by
35	P06_1/AN1/PPG1	
36	P06_2/AN2/PPG2	
37	P06_3/AN3/PPG3	
38	P06_4/AN4/PPG4	
39	P06_5/AN5/PPG5	
40	P06_6/AN6/PPG6	
41	P06_7/AN7/PPG7	
42	Vss	GND
43	P07_0/AN16/INT0/NMI	Key button 'INT0/NMI'
44	P07_1/AN17/INT1	Key button 'INT1'
45	P07_2/AN18/INT2	
46	P07_3/AN19/INT3	
47	P07_4/AN20/INT4	
48	P07_5/AN21/INT5	
49	MD2	to GND (w/ JP8 to + Vcc)
50	MD1	to + Vcc
51	MD0	Mode-Switch S1

Pin	Pin-name
52	RSTX
53	P07_6/AN22/INT6
54	P07_7/AN23/INT7
55	P08_0/TIN0/CKOTX0/ADTGN T12R
56	P08_1/TOT0/CKOT0/INT13
57	P08_2/SIN0/TIN2/INT14R
58	P08_3/SOT0/TOT2
59	P08_4/SCK0/INT15R
60	P08_5/SIN1/INT1R
61	P08_6/SOT1
62	P08_7/SCK1
63	Vcc
64	Vss
65	P09_0/PPG8/UBX
66	P09_1/PPG9/LBX
67	P09_2/PPG10/CS5
68	P09_3/PPG11/CS4




The Hardware



■ The microcontroller pins (cont'd)

Pin	Pin-name	On SK-16FX- EUROSCOPE used by
69	P09_4/OUT0/CS3	SEG1-E
70	P09_5/OUT1/CS2	SEG1-F
71	P09_6/OUT2/CS1	SEG1-G
72	P09_7/OUT3/CS0	SEG1-DP
73	P10_0/RX0/INT8R	CAN0 (RX)
74	P10_1/TX0	CAN0 (TX)
75	P00_0/AD00/INT8	SEG2-A
76	P00_1/AD01/INT9	SEG2-B
77	P00_2/AD02/INT10	SEG2-C
78	P00_3/AD03/INT11	SEG2-D
79	P00_4/AD04/INT12	SEG2-E
80	P00_5/AD05/INT13	SEG2-F
81	P00_6/AD06/INT14	SEG2-G
82	P00_7/AD07/INT15	SEG2-DP
83	P01_0/AD08/CKOT1/TIN1	
84	P01_1/AD09/CKOTX1/TOT1	

Pin	Pin-name
85	P01_2/AD10/INT11R/SIN3
86	P01_3/AD11/SOT3
87	P01_4/AD12/SCCK3
88	Vcc
89	Vss
90	X1
91	X0
92	P01_5/AD13/INT7R/SIN2R
93	P01_6/AD14/SOT2R
94	P01_7/AD15/SCCK2R
95	P02_0/A16/PPG12
96	P02_1/A17/PPG13
97	P02_2/A18/PPG14
98	P02_3/A19/PPG15
99	P02_4/A20/TTG8/INO
100	P02_5/A21/TTG9/TTG1/INI1 DTGR



The Software




- **The SK-16FX-EUROSCOPE CD includes the following:**
 - Softune Workbench (development platform for Fujitsu microcontrollers)
 - MCU Flash programming tool and SKwizard terminal program
 - USB driver for on board USB-to-RS232 converter
 - On-chip debugger “EUROScope lite 16FX“
 - Software examples for the SK-16FX-EUROSCOPE

- **Additionally you can order the latest „Fujitsu MICROSCOPE“:**
 - Includes documentation & software for all Fujitsu microcontrollers
 - Please contact your local [distributor](#)

- **Please check our dedicated microcontroller website:**
<http://www.fujitsu.com/us/services/edevicetronics/microcontrollers/>



- for updates of the Flash programmer tool, utilities and e
- for data sheets, hardware manuals, application notes, e




Installation of the USB-dr




- **Connect the SK-16FX-100PMC to your PC's USB port**
 - Windows will 'Found New Hardware: SK-16FX-100PMC' and the Hardware Wizard should start automatically
 - **Note: The installation procedure may differ with different operating systems.**



- Do not connect to Windows Update to search for software
- Select 'Install from a list or specific location (Advanced)'
- Within next windows select 'Search for the best driver' and browse on the CD to the folder 'drive:\USB-Driver\W




Installation of the USB-dr



- 'Continue anyway' although the Windows Logo test may fail
- Windows completes the installation by copying some files
- 'Finish' will close the window








Installation of the USB-dr




- Again Windows will 'Found New Hardware: USB Serial' the Hardware Wizard should start automatically
 - **Note:** The installation procedure may differ with different operating systems



- Do not connect to Windows Update to search for software updates
- Select 'Install from a list or specific location (Advanced)
- Within next windows select 'Search for the best driver' and browse on the CD to the folder 'drive:\USB-Driver\Windows'




Installation of the USB-dr



- 'Continue anyway' although the Windows Logo test may fail
- Windows completes the installation by copying some files






Installation of the USB-dr




- **Start the Device Manager of the Windows Control**
 - START -> Settings -> Control Panel
 - Control Panel -> System -> Hardware -> Device Manager
- **Check 'Ports' for the assigned virtual COM-port number**
 - FUJITSU Microcontroller board (e.g.: COM4)



Note:
Currently only COM ports are supported.
If the assigned COM port number is greater than 255, you must re-assign the device to a lower COM port in Windows.

- **Ready!**
 - The SK-16FX-100PMC can be powered via USB (default)
 - Depending on JP4 and JP5 one UART is connected to the other



The Development Software




■ Softune Workbench

- Free of charge, evaluation copy is available in MCU product
- Windows based development platform for all 16-bit microcontrollers
- Includes: Editor, C-compiler, assembler, linker, core simulator
- Supports optional hardware emulator
- Requires Registration
 - <http://www.onfulliment.com/FujitsuMicro/>
 - Receive your password for Softune Workbench by email
 - [Start installation](#)
 - Enter password and choose destination folder (e.g. C:\Program Files\FujitsuMicro)

■ EUROSCOPE

- Receive your license file for EUROSCOPE by email
- Contact mcugroup@fma.fujitsu.com

*1 Note: If you want to use EUROSCOPE please install and run it first a Host ID (MAC address) of your PC system. This ID is needed to be filled in the registration form to obtain a license key.




The FLASH Programmer




■ MCU Flash programmer

- Free of charge, no registration required
- Windows based programming tool for all 16-bit Fujitsu microcontrollers
- Uses PC serial port COMx (incl. virtual COM port: USB to serial)
- Download from the below link;

<http://www.fujitsu.com/us/services/edevelop/microelectronics/datailib/software/flpro16fx.html>





Tools and Software Exam



■ SKwizard

- Free of charge terminal program


<http://www.fujitsu.com/us/services/edevice/microelectronics/rs/datalib/software/flskwiz.html>

■ Following examples are provided with SK-16FX-EU11

- [sk16fx-euroscope_adc_dvm](#)
 - Digital Voltage Meter based on the A/D-converter
- [sk16fx-euroscope_can_uart_terminal](#)
 - Simple CAN example controlled by UART1
- [sk16fx-euroscope_counter](#)
 - Counts from 0 to 99 on the 7-segment Display
- [sk16fx-euroscope_template](#)
 - ,Empty' project as base for user applications
- [sk16fx-euroscope_uart](#)
 - UART example using UART1


Note:


Do not connect other than [EUROScope](#) to UART0 (default: [X5/USB](#)).
All examples are prepared to be used with EUROScope and UART0 is reserved.



Program Download

- Start the Fujitsu MCU Flash programmer
- Select the target microcontroller (MB96F348H/T)
- Select the crystal frequency (4 MHz)
- Choose the software example from the example 'A' (e.g. D:\Examples\sk-16fx-euroscope_counter-v10\ABS\sk-16fx-euroscope_






Program Download

- **Connect to the PC**
 - RS232 or USB can be used
 - Select COM port (,Set Environment')
- **Set jumper S1 to position ,Prog'**
- **Press ,Reset'**
- **Start ,Full operation'**


RS232
(see chap)



S1: Mode selection

Prog: Set switch to position ,Prog' in order to select the program-mode


Keyb



Fujitsu Microelectronics America Inc


All Rights Reserved






Program Download

- Close the MCU Flash programmer
- Set jumper S1 to position ,RUN‘
- Press ,Reset‘




S1: Mode selection

**Prog: Set switch to position ,RUN‘
in order to select the RUN-mode**




Keyb


Close the F



New Project

- **In order to start a new user project use the template**
 - This project includes the startup code, header files, and
- **Copy the folder 'Template' within the example folder**
 - Rename 'Copy of sk-16fx-euroscope_v10' to 'Template'






New Project

- **Enter 'my_application'-folder**
 - Rename 'template.prj' into 'my_application.prj'
 - Rename 'template.wsp' into 'my_application.wsp'
- **Edit 'my_application.prj'**
 - rename 'sk16fx_template' -> 'my_application'
- **Edit 'my_application.wsp'**
 - rename 'sk16fx_template' -> 'my_application'



```
sk16fx_template.prj - Notepad
File Edit Format View Help
[DirInfo]
PRJ=C:\work\sk16fx\sk16fx_template-v10\
[MEMBER-Debug]
F0=5
F1=0 m 1 AB6\sk16fx_template.abs
F2=0 a 1 src\start.asm
F3=1 c 1 src\main.c
F4=1 c 1 src\mb96300.h
F4-1=- src\mb96300.h
F5=0 a 1 src\Mb96300.asm
```


```
sk16fx_template.wsp - Notepad
File Edit Format View Help
[PrjFile]
Count=1
FILE=C:\sk16fx_template
ActivePrj=sk16fx_tem
[subprj-sk16fx_tem]
Count=0
[DebState]
AutoSave=1
Exec=0
AutoLoad=1
[DirInfo]
WSP=C:\work\sk16fx\s
```




New Project



- Start Softune Workbench and open your project







New Project



■ Write your application code

- Start.asm : Startup code
- Vectors.c : Vector table
- Main.c : Your application






New Project




■ Compile and build your project

- Generates the MHX-file, which can be programmed to the microcontroller

Compile






New Project



Congratulations

- **You have finished your first project**
- Please see our application note [‘16FX Getting Started’](#) for a more detailed introduction.




EUROScope lite 16FX




- „EUROScope lite 16FX“ source-level debugger
 - On-chip debugging for 16FX microcontroller
 - No kernel linkage / upload required
 - Breakpoints
 - Single step debugging (step, step-in, step-out)
 - Windows for memory, watch, mixed source code, registers
 - Plug-ins available for operating systems etc.






EUROScope lite 16FX Installation

- Installation of „EUROScope lite 16FX“
 - Start „[EUROScope lite 16FX](#)“ for installation
 - Choose „Fujitsu F16LX / F16FX“ from list







EUROScope lite 16FX Installation

- License for „EUROScope lite 16FX“
 - Run EUROScope.exe
 - Copy Host ID (MAC address) of your PC system
 - Request Lite key at mcugroup@fma.fujitsu.com
 - Receive license key file from company EUROS by e-mail
 - Copy license key file (*euross-lite.key*) to your local hard disk



Host ID of
your PC
system





EUROScope lite 16FX Project preparation




- All examples within this package are already prepared with EUROScope
 - [Default connection: UART0 routed to X5/USB](#).

- In case of new projects or project modifications
 - Use Softune Workbench
 - Setup the Background Debugging area
 - See *Start.asm* (v1.28), chapter 4.18 (Enable Background Mode) and chapter 5.9 (Debug Address Specification)
 - See always the latest ‘sk-16fx-euroscope_template’
 - Built your application project with Softune Workbench
 - Loadmodule (*.abs) format is required for debugging


- **Download your project (*.mhx) to the board**
 - Use the Fujitsu MCU Flash programmer






EUROScope lite 16FX Configuration

- **Start EUROScope**
- **Ensure the following settings**
 - Select Target Connection ①
 - Choose Fujitsu 16FXBootROM (RS232)
 - Configure Target Connection ②
 - Choose the COM port of the **Debug-UART** (Default: UART0 routed to X5/USB)
 - Choose the baudrate used in the Debug Address Specification of the *Start.asm* file (Default: 115200)
 - Choose „asynchronous communication“ and „Int/Ext vector mode“





EUROScope lite 16FX


Load ABS file




- Load the *abs* file of your project
- File / Open Application ...

E.g.: <drive>:\Examples\sk16fx_euroscope_counter-v10\ABS\sk16fx_euroscope_counter

- Projects may be compiled on another PC or folder than the debug PC
- Adjust the source path ①
 - Click New (Insert) ②
 - Browse to source folder ③
 - E.g.: <drive>:\Examples\sk16fx_euroscope_counter-v10\Src





EUROScope lite 16FX Start Debugging



- Initialize target and run until main function




- Use menu bar for debugging

Set Start address

Run


Stop

Set br



Single Step
(over
functions)

Step in




EUROScope lite 16FX Breakpoints

- **Set a breakpoint**
 - Double-click to desired line
 - ,C' code source: selectable lines are marked by sn
 - ,Assembly' window: all lines with an instruction can
 - Some lines in source code window are grouped. When breakpoint all grouped lines getting the red filled circle treated as only one breakpoint

- **Activate/deactivate breakpoints**
 - Single-click to breakpoint

- **Delete breakpoint**
 - Double-click to breakpoint until red filled (or white filled)





EUROScope lite 16FX

Breakpoints



Short explanation of EUROScope source code window

Yellow arrow shows actual program counter


Point indicates source code

```
131 while(1)
132 {
133     if (SSR1_RDRF != 0)
134     {
135         ch = RDR1;
136         if ((SSR1 & 0xE0) != 0)
137             SCR1_CRE = 1;
138     }
139 }
```

Active

Deactivated

Lines between points indicate a group of breakable lines




EUROScope lite 16FX Processor Status

- Processor window provides most important registers
- All processor flags are shown individually
- All values can be changed
- Window is updated on any stop or break of the application
- Changes in values are displayed in red due to price



```
Register: unknown register
RL0=01CC0000  RL1=00F80004  RL2=00020000
RL3=00F80000
RW0=0000  RW1=01CC  RW2=0004  RW3=00F8
RW4=0000  RW5=0002  RW6=0000  RW7=00F8
R0=00  R1=00  R2=02  R3=00  R4=00  R5=00
R6=F8  R7=00
A=00660066  AH=0066  AL=0066
PC=F80169  SSP=00253E  USP=002544
DPR=22  DTB=00  ADB=00
PS=EOE5  ILM=7  RP=00  CCR=E5
I=1  S=1  T=0  N=0  Z=1  V=0  C=1  TBR=0000
```




EUROScope lite 16FX Variable Window

- **Local**
 - Local variables are automatically collected in view „Local“
- **Watch**
 - All local and up to 8 global variables can be added individually in the ‘Watch’ window
- **Variables are updated on any stop or break of the program**
- **Changed values are displayed in red**
- **Variable values can be changed in ‘value’ entry**






Variable	Value	Type	Storage	Module	Address	Size
cnt1	22	char	0x2246	main	0x2246	1 byte
cnt2	9	char	0x2245	main	0x2245	1 byte
cntdir	0	char	0x2244	main	0x2244	1 byte
delay	40144	unsigned long	0x2240	main	0x2240	4 byte



EUROScope lite 16FX Changing/Adding Source

- **New source module window**
 - Go in window tab area and right-button click
 - Choose „New Source window“
- **Change source window**
 - Get menu by right-mouse-button-click in the source window
 - Choose „Show Module...“
 - Browse to Module File






EUROScope lite 16FX Flash Programming




- **Flash programming is available via the Flash button**
 - BDM configuration can be set before programming
 - Chip erase is supported
 - Flash programming is supported
 - User has to press reset button after Flash programming
 - Fujitsu Flash programming kernels are reused



EUROScope lite 16FX BDM Configuration




- Background debugging mode configuration
- Flash security unlock



Flash security unlock

BDM Activation
[√] Use EUROScope con
[] Use MHX file configur



EUROScope lite 16FX Flash Programming Dialog

■ Chip erase and Flash programming


- Click on 'Done' and reset board after programming

The screenshot shows the 'Flash Programming' dialog box. Callouts point to the following elements:

- Chip**: Points to the 'Chip' field showing 'Flash 0_00DF0000h...01037FFFh 2336 KB MB96F348RSA internal flash'.
- Sectors**: Points to the list of sectors, with 'Flash 0 Sector 36' selected.
- Brows**: Points to the 'File' field showing 'C:\Work\...\Customer_Problems\EUROS\VRMS_MER\ABS\16FX-963'.
- Flash pro**: Points to the 'Program' button.

Other visible elements include 'Erase', 'Verify', 'Done', 'Info', and 'Progress' sections.






EUROScope lite 16FX Prospect




- **All SK16FX-EUROSCOPE examples are configured**
 - UART0 for debugging
 - UART1 may be used by the application
 - Asynchronous communication
 - 115200 Bits/s
 - Autorun after reset
 - No breakpoint predefinition



Further Steps



- **In order to learn more about Fujitsu's microcontrollers**
 - Visit our microcontroller website
 - <http://www.fujitsu.com/us/services/edevices/microcontrollers/>
 - See our application notes
 - <http://www.fujitsu.com/us/services/edevices/microcontrollers/datalib/appnotes/index.html>
 - See our software examples
 - <http://www.fujitsu.com/us/services/edevices/microcontrollers/datalib/software/index.html>
- **Contact your local distributor ...**
 - for individual support
 - to order the latest 'Fujitsu Micros DVD' containing all information regarding Fujitsu's 8-bit, 16-bit, and 32-bit microcontrollers



Optional Tools



■ High-end evaluation board

- Flash-Can-100P-340 (Supports QFP package M06/M22)
- ADA-91270-90340-100PFV (Adapter for LQFP/PMC package)



■ Hardware emulator

- MB2198-01 + MB2198-500
- Emulation chip MB96V300B
- Probe header MB2198-502 for LQFP package M05/M2
- Socket NQPACK100SD-ND, HQPACK100SD
- Probe header MB2198-501 for QFP package M06/M22
- Socket NQPACK100RB179 +HQPACK100RB179




■ Programmer

- Conitec GALEP-4



■ Operating systems




Evaluation Board



■ **Flash-Can-100P-340 V2.0**

- Evaluation board for MB96340 Series (for QFP package)
- Emulator target board
- Access to all on-chip peripherals
- 2x UART
- 2x CAN
- 2x LIN
- 8x 'User'-LEDs
- 5x 'User'-Buttons
- Flash-Kit connector
- Connector for LC-Display
- Example projects






Evaluation Board

- **ADA-91270-90340-100PFV**
 - Adapter for LQFP package M05/M20
 - Optional for Flash-Can-100P-340






Hardware Emulator



■ In-Circuit emulator for F2MC-16FX

- Main unit (MB2198-01), Adapter (MB2198-500), V-Chip
- USB, LAN, and RS232 communication interface
- Connected to target system via standard Fujitsu probe
- High speed operating frequency
- 2052 code / 4 data event breakpoints
- Sequential breakpoints (4 conditions / 3 levels)
- Trace function





Hardware Emulator




- **Emulation chip MB96V300B**
 - Superset supports all features of 16FX

- **Probe header**
 - MB2198-502 for LQFP package M05/M20
 - MB2198-501 for QFP package M06/M22

- **Socket for LQFP package M05/M20**
 - NQPACK100SD-ND, HQPACK100SD
- **Socket for QFP package M06/M22**
 - NQPACK100RB179, HQPACK100RB179






Programmer



■ GALEP-4 / GALEP-5

- Supports parallel programming
- Supports serial synchronous and asynchronous programming
- Optional programming cable for serial synchronous programming
- Allows programming in volume production
- www.conitec.com





Contact Information



For any MCU Technical Support, please contact
mcugroup@fma.fujitsu.com

Looking for pricing, stock, or lifecycle information?

Click below to explore more details on WIN SOURCE:

 [View SK-16FX-EUROSCOPE on WIN SOURCE](#)

 [Cypress Semiconductor Corp](#) Information

Optimize Your Supply Chain with WIN SOURCE Solutions

-  Global Sourcing Solution
-  Obsolete Management
-  Cost Control Management
-  Shortage Management
-  Alternative Solution
-  Excess Inventory Management