



THE DATASHEET OF
25060/60 BK005



Alpha Wire Part Number Ordering Guide

Step 1: Start with the base part number (sometimes classified as the item number).

Ex: 5002C, 9008A, V16001, 1550, FIT-221-1/8

Step 2: Then choose jacket color, use the abbreviation

Color Putup	Color (jacket)
BK	Black
BL	Blue
BR	Brown
GR	Green
GY	Green/Yellow
NA	Natural
OR	Orange
RD	Red
SL	Slate
VI	Violet

Step 3: Choose put up code, use the abbreviation for the part number

Put Up Code	Description
001	1000 FT
002	500 FT
005	100 FT
021	Box 1000 FT
066	14X6 Inches

Step 4: Alpha Wire Part Number Examples

Item Number: 5002C

Item Color: Gray/Slate

Item Put Up: 1000 Ft

Part Number System: 5002C SL001

Item Number: 3070

Item Color: Black

Item Put Up: 100 Ft

Part Number System: 3070 BK005

Conductor Color Coding

The Put Up information listed below is specifically regarding Alpha Wire's Hook Up Wire and not related to any other product line.

Hook-Up Wire

Chart Z1	
No.	Color
1	White
2	Black
3	Red
4	Green
5	Yellow
6	Blue
7	Brown
8	Orange
9	Slate
10	Violet
11	White/Black
12	White/Red
13	White/Green
14	White/Yellow
15	White/Blue
16	White/Brown
17	White/Orange
18	White/Slate
19	White/Violet
28	Green/Yellow
29	Yellow/Green
30	Pink

Chart Z2	
No.	Colors
0	Black
1	Brown
2	Red
3	Orange
4	Yellow
5	Green
6	Blue
7	Violet
8	Slate
9	White
45	Yellow/Green
54	Green/Yellow
90	White/Black
91	White/Brown
92	White/Red
93	White/Orange
94	White/Yellow
95	White/Green
96	White/Blue
97	White/Violet
98	White/Slate
P	Pink
T	Tan
X	Clear

Looking for pricing, stock, or lifecycle information?

Click below to explore more details on WIN SOURCE:

 [View 25060/60 BK005 on WIN SOURCE](#)

 [Alpha Wire](#) Information

Optimize Your Supply Chain with WIN SOURCE Solutions

-  Global Sourcing Solution
-  Obsolete Management
-  Cost Control Management
-  Shortage Management
-  Alternative Solution
-  Excess Inventory Management