



**THE DATASHEET OF
EVAL-ADUC7020QSPZ**



ADuC7020 Evaluation Board Reference Guide MicroConverter[®] ADuC7020 Development System

by Aude Richard

TABLE OF CONTENTS

| | |
|---------------------------------|---|
| Evaluation Board Overview | 1 |
| Evaluation Board Features | 1 |
| DIP Switch Link Options | 2 |
| External Connectors | 3 |
| Demonstration Circuit | 4 |
| Parts List | 5 |

OVERVIEW

The ADuC7020 evaluation board has the following features:

- 2-layer PCB (4" × 5" form factor)
- 9 V power supply regulated to 3.3 V on board
- 4-pin UART header to connect to RS232 interface cable
- 20-pin standard JTAG connector to connect to ULINK emulator
- Demonstration circuit
- 32.768 kHz watch crystal to drive the PLL clock
- ADR291 2.5 V external reference chip
- Reset/Download/IRQ0 push-buttons
- Power indicator/general-purpose LEDs
- Access to all ADC inputs and DAC outputs from external header. All device ports are brought out to external header pins.
- Surface-mount and through-hole general-purpose prototype area

Notes

1. This document refers to the MicroConverter ADuC7020 Evaluation Board Rev. A.
2. All references in this document to physical orientation of components on the board are made with respect to a component side view of the board, with the prototype area appearing in the bottom of the board.
3. The board is laid out to minimize coupling between the analog and digital sections of the board. The ground plane is split with the analog section on the left-hand side and a digital plane on the right-hand side of the board. The regulated 3.3 V power supply is routed directly to the digital section, and is filtered before being routed into the analog section of the board.

REV. 0

FEATURES

Power Supply

The user should connect the 9 V power supply via the 2.1 mm input power socket (J5). The input connector is configured as CENTER NEGATIVE, i.e., GND on the center pin and 9 V on the outer shield.

This 9 V supply is regulated via a linear voltage regulator (U5). The 3.3 V regulator output is used to directly drive the digital side of the board. The 3.3 V supply is also filtered, and is then used to supply the analog side of the board.

When on, the red LED (D3) indicates that a valid 3.3 V supply is being driven from the regulator circuit. All active components are decoupled with 0.1 μ F at device supply pins to ground.

RS232 Interface

The ADuC7020 (U1) P1.1 and P1.0 lines are connected to the RS232 interface cable via connector (J1). The interface cable generates the required level shifting to allow direct connection to a PC serial port. Ensure that the cable supplied is connected to the board correctly, i.e., DV_{DD} is connected to DV_{DD}, and DGND is connected to DGND.

Emulation Interface

Nonintrusive emulation and download are possible on the ADuC7020 via JTAG by connecting the ULINK emulator to the J4 connector.

Crystal Circuit

The board is fitted with a 32.768 kHz crystal from which the on-chip PLL circuit can generate a 45 MHz clock.

External Reference (ADR291)

The external 2.5 V reference chip (U2) has two functions. It is provided on the evaluation board to demonstrate the external reference option of the ADuC7020, but its main purpose is to generate the V_{OCM} voltage of the differential amplifier, if required.

Reset/Download/IRQ0 Push-Buttons

A RESET push-button is provided to allow the user to manually reset the part. When inserted, the RESET pin of the ADuC7020 is pulled to DGND. Because the RESET pin on the ADuC7020 is Schmitt-triggered internally, there is no need to use an external Schmitt trigger on this pin.

When inserted, the IRQ0 push-button switch drives

P0.4/IRQ0 high. This can be used to initiate an external interrupt 0.

To enter serial download mode, the user must pull the P0.0/BM pin low while reset is toggled. On the evaluation board, serial download mode can be easily initiated by holding down the serial download push-button (S2) while inserting and releasing the reset button (S3), as illustrated in Figure 1.

Power Indicator/General-Purpose LEDs

A red power LED (D3) is used to indicate that a sufficient supply is available on the board. A general-purpose LED (D2) is directly connected to P4.2 of the ADuC7020. When P4.2 is cleared, the LED is turned on; when P4.2 is set, the LED is turned off.

Analog I/O Connections

All analog I/O connections are brought out on header J3.

ADC0 and ADC1 are buffered using an AD8606 to evaluate single-ended and pseudo differential mode. A potentiometer can be connected to ADC0 buffered. ADC3 and ADC4 can be buffered with a single-ended-to-differential op amp on board, with the AD8132 used to evaluate the ADC in fully differential mode.

ADC2 is not buffered. Be sure to follow the data sheet recommendations when connecting signals to this input.

DAC1 can be used to control the brightness of the green LED, D1, when connected via the S1 switch.

General-Purpose Prototype Area

A general-purpose prototype area is provided at the bottom of the evaluation board for adding external components as required in the user's application. As can be seen from the layout, AV_{DD}, AGND, V_{DDIO}, and DGND tracks are provided in this prototype area.

DIP SWITCH LINK OPTIONS

S1-1 V_{REF}

Function: Connects the output of the 2.5 V external reference (ADR291) to the V_{REF} pin (Pin 35) of the ADuC7020.

Use: *Slide S1-1 to the ON position* to connect the external reference to the ADuC7020.

Slide S1-1 to the OFF position to use the internal 2.5 V reference or a different external reference on the V_{REF} pin of the J3 header.

S1-2 V_{OCM}

Function: Connects 1.67 V to the V_{OCM} pin of the AD8132. No extra dc voltage is required on the board to use the ADC in differential mode.

Use: *Slide S1-2 to the ON position* to connect V_{OCM} of the differential amplifier to 1.67 V, divided output of the ADR291 reference.

Slide S1-2 to the OFF position to use a different voltage for V_{OCM} by connecting a dc voltage to the V_{OCM} pin of the J3 header. Note that V_{OCM} value is dependent on reference value, as shown in Table I.

Table I. V_{OCM} Range

| V _{REF} | V _{OCM min} | V _{OCM max} |
|------------------|----------------------|----------------------|
| 2.5 V | 1.25 V | 2.05 V |
| 2.048 V | 1.024 V | 2.276 V |
| 1.25 V | 0.75 V | 2.55 V |




Figure 1. Entering Serial Download Mode on the Evaluation Board

S1-3 POT

Function: Connects the potentiometer output to ADC0. This input is buffered by an AD8606. This is for demonstration purposes.

Use: **Slide S1-3 to the ON position** to connect the potentiometer to the op amp of the ADC0 input channel.

Slide S1-3 to the OFF position to use the ADC0 input on the J3 header.

S1-4 ADC3

Function: Brings out ADC3 (Pin 1) on the J3 header.

Use: **Slide S1-6 to the ON position** to connect ADC3 of the J3 header directly to the ADC3 pin (Pin 1) of the ADuC7020.

Slide S1-6 to the OFF Position to disconnect ADC3 of the J3 header from the ADC3 pin (Pin 1) of the ADuC7020.

S1-5 VIN-

Function: Connects -OUT of the single-ended-to-differential op amp (AD8132) to ADC3. S1-5 and S1-6 must be used together when VIN- is in the ON position; VIN+ must also be in the ON position to use the differential op amp on channels ADC3 and ADC4.

Use: **Slide S1-5 to the ON position** to connect -OUT of the AD8132 to ADC3.

Slide S1-5 to the OFF position to use ADC3 without the AD8132.

S1-6 VIN+

Function: Connects +OUT of the single-ended-to-differential op amp (AD8132) to ADC4. When VIN+ is in the ON position, VIN- must also be in the ON position to use the differential op amp on channels ADC3 and ADC4.

Use: **Slide S1-6 to the ON position** to connect +OUT of AD8132 to ADC4.

Slide S1-6 to the OFF position to use ADC4 without the AD8132.

S1-7 ADC4

Use: **Slide S1-6 to the ON position** to connect ADC4 of the J3 header directly to the ADC4 pin (Pin 2) of the ADuC7020.

Slide S1-6 to the OFF position to disconnect ADC4 of the J3 header from the ADC4 pin (Pin 2) of the ADuC7020.

S1-8 LED

Function: Connects the DAC1 output to the green LED of the demo circuit, D1.

Use: **Slide S1-7 to the ON position** to connect the DAC1 output to D1.

Slide S1-7 to the OFF position to use the DAC1 output on the J3 header.

EXTERNAL CONNECTORS**J3 Analog I/O Connector**

The analog I/O connector J3 provides external connections for all ADC inputs, reference inputs, and DAC outputs. The pinout of the connector is shown in Table II.

Table II. Pin Functions for Analog I/O Connector J3

| Pin No. | Pin Description |
|---------|-------------------|
| J3-1 | AV _{DD} |
| J3-2 | AGND |
| J3-3 | V _{REF} |
| J3-4 | ADC0 |
| J3-5 | ADC1 |
| J3-6 | ADC2 |
| J3-7 | ADC3 |
| J3-8 | ADC4 |
| J3-9 | V _{DIFF} |
| J3-10 | V _{OCM} |
| J3-11 | DAC0 |
| J3-12 | DAC1 |
| J3-13 | DAC2 |
| J3-14 | DAC3 |

J5 Power Supply Connection

J5 allows for the connection between the evaluation board and the 9 V power supply provided in the ADuC7020 development system.

J4 Emulation Connector

J4 provides a connection of the evaluation board to the PC via a USB cable and ULINK provided in the ADuC7020 development system.

J1 Serial Interface Connector

J1 provides a simple connection of the evaluation board to the PC via a PC serial port cable provided with the ADuC7020 development system.

J6 I²C[®] Interface Connector

J6 provides a simple access to the two I²C interfaces of the ADuC7020.

J2 Digital I/O Connector

The digital I/O connector J2 provides external connections for all GPIOs. The pinout of the connector with pin function descriptions is shown in Table III.

Table III. Pin Functions for Digital I/O Connector J2

| Pin No. | Pin Description |
|---------|--|
| J2-1 | DGND |
| J2-2 | P4.2 PLAO[10] |
| J2-3 | P1.0 SIN/SCL/PLAI[0] |
| J2-4 | P1.1 SOUT/SDA/PLAI[1] |
| J2-5 | P1.2 RTS/PLAI[2] |
| J2-6 | P1.3 CTS/PLAI[3] |
| J2-7 | P1.4 RI/CLK/PLAI[4] |
| J2-8 | P1.5 DCD/MISO/PLAI[5] |
| J2-9 | P1.6 DSR/MOSI/PLAI[6] |
| J2-10 | P1.7 DTR/CSL/PLAO[0] |
| J2-11 | P0.7 ECLK/SIN/PLAO[4] |
| J2-12 | P2.0 CONV/SOUT/PLAO[5] |
| J2-13 | P0.5 IRQ1/ADC _{BUSY} /PLAO[2] |
| J2-14 | P0.4 IRQ0/ PLAO[1] |
| J2-15 | P0.3 TRST/ADC _{BUSY} |
| J2-16 | P0.6 MRST/PLAO[3] |
| J2-17 | P0.0 CMP/PLAI[7] |
| J2-18 | DGND |

POTENTIOMETER DEMONSTRATION CIRCUIT




Figure 2. Circuit Diagram of the RTD Circuit

Using the sample code in `\code\adc\pot.c`, the variation in the potentiometer resistance can be seen on the output LED. Note that the internal reference and external reference are 2.5 V, which gives an ADC input range of 0 V to 2.5 V in single-ended mode. The potentiometer can give a voltage between 0 V and $AV_{DD} = 3.3$ V.

ADuC7020 EVALUATION BOARD PARTS LIST

| Component | Qty. | Part | Description | Order No. | Order From |
|---------------------------------|------|-----------------------------|--|-----------------|------------------|
| EVAL-ADuC7020QS QuickStart™ PCB | 1 | PCB-1 | 2-Sided Surface-Mount PCB | | |
| PCB Stand-Off | 4 | Stand-Off | Stick-On Mounting Feet | 148-922 | Farnell |
| U1 | 1 | ADuC7020 | MicroConverter (64-CSP) | ADuC7020CP | ADI |
| U2 | 1 | ADR291 | Band Gap Reference | ADR291ER | ADI |
| U3 | 1 | AD8132 | Differential Op Amp | AD8132ARM | ADI |
| U4 | 1 | AD8606 | Dual Op Amp, (8-Lead SOIC) | AD8606AR | ADI |
| U5 | 1 | ADP3333 | Fixed 3.3 V Linear Voltage Regulator | ADP3333ARM3.3 | ADI |
| Y1 | 1 | 32.768 kHz | Watch Crystal | 316-0312 | Farnell |
| S1 | 1 | SW\8-DIP | 8-Way DIP Switch | 566-718 | Farnell |
| S2, S3, S4 | 3 | Push-Button Switch | PCB-Mounted Push-Button Switch | 177-807 | Farnell |
| D1, D2, D3 | 3 | LED | 1.8 mm Miniature LED | 515-620 | Farnell |
| D4 | 1 | PRLL4002 | Diode | BAV103DITR-ND | Digi-Key |
| C1, C5, C13, C15, C18, C22, C23 | 7 | 10 μ F | Surface-Mount Tantalum Cap, Taj-B Case | 197-130 | Farnell |
| C2-C4, C6, C12, C14, C16, C17 | 8 | 0.1 μ F | Surface-Mount Ceramic Cap, 0603 Case | 317-287 | Farnell |
| C7, C8 | 2 | 22 pF | Surface-Mount Ceramic Cap, 0603 Case | 722-005 | Farnell |
| C11, C19 | 2 | 470 nF | Surface-Mount Ceramic Cap, 0603 Case | 318-8851 | Farnell |
| R1 | 1 | 10 k Ω Potentiometer | 0.25 W, 4 Series, 4 mm Square Sealed | 307-1741 | Farnell |
| R2 | 1 | 100 Ω | Surface-Mount Resistor, 0603 Case | 911-732 | Farnell |
| R3 | 1 | 200 Ω | Surface-Mount Resistor, 0603 Case | 321-7978 | Farnell |
| R4 | 1 | 49.9 Ω | Surface-Mount Resistor, 0805 Case | 422-1825 | Farnell |
| R5, R6, R8, R9 | 4 | 348 Ω | Surface-Mount Resistor, 0603 Case | 422-2570 | Farnell |
| R7 | 1 | 24.9 Ω | Surface-Mount Resistor, 0805 Case | 422-1539 | Farnell |
| R10, R11 | 2 | 60.4 Ω | Surface-Mount Resistor, 0805 Case | 422-1904 | Farnell |
| R12, R18, R20 | 2 | 270 Ω | Surface-Mount Resistor, 0603 Case | 613-022 | Farnell |
| R13, R14 | 2 | 0 Ω | Surface-Mount Resistor, 0603 Case | 772-227 | Farnell |
| R15-R17 | 4 | 1 k Ω | Surface-Mount Resistor, 0603 Case | 911-239 | Farnell |
| R19 | 1 | 1.5 Ω | Surface-Mount Resistor, 0603 Case | 758-267 | Farnell |
| R21, R22, R24 | 3 | 100 k Ω | Surface-Mount Resistor, 0603 Case | 911-471 | Farnell |
| L1 | 1 | Ferrite Bead | Surface-Mount Inductor, 1206 Case | 581-094 | Farnell |
| J1 | 1 | 4-Pin Header | 4-Pin 90° Single Row Header | TSM-104-02-T-SH | Samtec |
| J2 | 1 | 18-Pin Header | 18-Pin Straight Single Row Header | TSM-118-01-T-SV | Samtec |
| J3 | 1 | 14-Pin Header | 14-Pin Straight Single Row Header | TSM-114-01-T-SV | Samtec |
| J4 | 1 | 20-Pin Header | 20-Pin Connector | IMP-BV(SMT)-20 | Imperial-Connect |
| J5 | 1 | | PCB-Mounted Socket (2 mm Pin Diameter) | KLD-SMT2-0202-A | Kycon |

Purchase of licensed I²C components of Analog Devices or one of its sublicensed Associated Companies conveys a license for the purchaser under the Philips I²C Patent Rights to use these components in an I²C system, provided that the system conforms to the I²C Standard Specification as defined by Philips.





Figure 3. ADuC7020 Evaluation Board Schematic



ADuC7020 EVALUATION BOARD Rev. A- Component Side View

Silkscreen Top

Figure 4. ADuC7020 Evaluation Board Silkscreen

Looking for pricing, stock, or lifecycle information?

Click below to explore more details on WIN SOURCE:

 [View EVAL-ADUC7020QSPZ on WIN SOURCE](#)

 [Analog Devices Inc. Information](#)

Optimize Your Supply Chain with WIN SOURCE Solutions

-  Global Sourcing Solution
-  Obsolete Management
-  Cost Control Management
-  Shortage Management
-  Alternative Solution
-  Excess Inventory Management